

The Museum of T&M Instruments
Collector's Assistance

Vacuum Tube Exchange List

European Type	U.S. Type	USSR Type
EAA91 / EB91	6AL5	
EABC80	6AK8	
EBC81	6BD7-A	
EBC90	6AT6	
EBC91	6AV6	
EBF80	6N8	
EBF83	6DR8	
EBF89	6DC8 / 7125	
EC80	6Q4	
EC81	6R4	
EC84	6AJ4	
EC86	6CM4	
EC88	6DL4	
EC91	6AQ4	
EC92	6AB4	
EC93	6BS4	
EC94	6AF4	
ECC230	6AS7-G / 6080	
ECC808	6KX8	
ECC81	12AT7	
ECC82	12AU7	
ECC83	12AX7	
ECC84	6CW7	
ECC85	6AQ8	
ECC86	6GM8	
ECC91	6J6	
ECF80	6BL8	
ECH81	6AJ8	
ECH83	6DS8	
ECL80	6AB8	
ECL82	6BM8	
ECL86	6GW8	
EF80	6BX6	
EF85	6BY7	
EF86	6BK8 / 6267	
EF89	6DA6	
EF91	6AM6	
EF92	6CQ6	
EF93	6BA6	
EF94	6AU6	
EF95	6AK5	
EF96	6AG5	
EF97	6ES6	
EF98	6ET6	
EH90	6CS6	
EK90	6BE6	
EL34	6CA7	
EL81	6CJ6	
EL82	6DY5	
EL83	6CK6	
EL84	6BQ5	
EL86	6CW5	
EL90	6AQ5	
EL91	6AM5	
EL95	6DL5	
EM80	6BR5	
EM87	6HU6	
EQ80	6BE7	
EZ80	6V4	
EZ90	6X4	
EZ91	6AV4	